Lincat Waterboiler

Catering for Hot Drinks

(FOR SMALL QUANTITIES OF HOT WATER PLEASE USE KETTLES PROVIDED)

SWITCH ON AT THE ELECTRIC SOCKET

(BEHIND WATER BOILER)

The unit will display 'WAIT'

whilst it fills and heats - allow 30 minutes

It will display 'READY' when water can be drawn off

PLEASE SWITCH OFF UNIT AT SOCKET

BEFORE YOU LEAVE